

Change Tools

Written By: Ethan Alexander Hays




Introduction

how to take out and put in tools using the power drawbar

Step 1 — Inserting a tool









- Hold the tool in the machine and make sure the tool holder is lined up with the block on the quil.
- Press "IN" on the power drawbar. Make sure the tool holder is fully seated.

Step 2 — Removing a tool



- Lock the quil.
- Hold the tool holder and press "OUT" on the power drawbar.

Step 3 — Tips



- Tools holders will get "stuck" if:
 - The tool holders have corrosion(Clean with abrasive pads)
 - Quil is not all the way up
 - Power drawbar was overtightened (tap tool holder with mallet)